



(a) VEH. Nº 46/0001 ⇔ 46/0050 - 46A 709 ☒ Δ 46A 709

(b) VEH. Nº 46/0051 - A46A 709

Lotus Europa S1 Parts Manual - Section A - Chassis - Page 2

Item	Lotus #	S1	S1A/B	S2	S2 Fed	TC	TC Fed	TCS	TCS F	LHD	RHD	Description	Change Point Notes Bulletin Reference
46A701	46A701	1	1									Chassis Frame	
46B6001	46B6001	2	2									Eye Bolt - Tie tube/seat belt mounting	
A07W1409	A07W1409	2	2									Washer - Tie tube/seat belt mounting	
46B1177	46B1177	1	1									Tie Tube L/H	
46A709	46A709	1	1									Cross Beam	Replaced by 054A0709 Up to Chassis No. 0050
A46A709	A46A709	1	1									Cross Beam	Replaced by 054A0709
LUFN050F	LUFN050F	4	4									Nut - Cross Beam to Chassis	5/16" x 24 TPI, 1/2" head
LUFN050F	LUFN050F	2	2									Nut - Tie Tube to Chassis	5/16" x 24 TPI, 1/2" head
46A708	46A708	1	1									Gearbox Mount Cross Bar Assembly	
46A169	46A169	1	1									Gearbox Mount Cross Bar	
W060	W060	2	2									Washer - Gearbox to Mount	
46A002	46A002	2	2									Gearbox Mount Bracket	
XUFS0524	XUFS0524	2	2									Bolt - Tie Tube to Chassis	
A05W1007	A05W1007	2	2									Washer - Tie Tube to Chassis	1/16" thick, 5/8" OD and 9/32" ID
46B1178	46B1178	1	1									Tie Tube R/H	
46A702	46A702	1	1									Front Box - Chassis	
XXXX	XXXX	6	6									Bolt - Body to chassis in seat area	1 1/2" long, 1 1/2" thread length, 5/32" x 32 TPI, 5/16" head
XXXX	XXXX	6	6									Nut - Body to chassis in seat area	5/32" x 32 TPI, 5/16" head, Nyloc
XXXX	XXXX	30	30									Washer - Body to chassis in seat area	1/16" thick, 1" OD, 7/32" ID
XUFS0516	XUFS0516	4	4									Bolt - Cross Beam to Chassis	