

Lotus Europa S1 Parts Manual - Section H1 - Steering - Column and Steering Unit - Page 2

Item	Lotus #	S1	S1A/B	S2	S2 Fed	TC	TC Fed	TCS	TCS F	LHD	RHD	Description	Change Point Notes Bulletin Reference
36H6023	36H6023	1	1									Cap	
36H6024	36H6024	1	1									O Ring	
36H6025	36H6025	1	1									Spring	
36H6029	36H6029	1	1									Clip - Bellows - Steering Rack	
36H6015	36H6015	1	1									Steering Rack Housing	
36H6039	36H6039	1	1									Ground Strap	
36H6003	36H6003	1	1									Universal Joint	
46H049	46H049												
36H6026	36H6026	1	1									Spacer	
36H6018	36H6018	1	1									Washer	
36H6017	36H6017	1	1									Spacer	
14H87	14H87	2	2									Mounting Bracket - Steering Rack	
A04W0905	A04W0905	4	4									Washer - Mounting Bracket - Steering Rack	1/32" thick, 1/2" OD, 1/4" ID
AUFN040F	AUFN040F	4	4									Nut - Mounting Bracket - Steering Rack	7/16" head, 1/4" x 28 TPI
36H6002	36H6002	1	1									Universal Joint	
36H6022	36H6022	1	1									Circlip	
36H6021	36H6021	1	1									Seal	
36H6020	36H6020	1	1									Spacer	
36H6019	36H6019	1	1									Spring	
36H6016	36H6016	1	1									Steering Gear	
36H6036	36H6036	1	1									Steering Rack	
36H6006	36H6006	1	1									Steering Wheel	
36H6005	36H6005	1	1									Brush - Horn contact	
36H6008	36H6008	1	1									Clip - Horn push retaining	
28H030	28H030	1	1									Horn Button	
36H6004	36H6004	1	1									Horn push or 036M6090	
36H6035	36H6035	1	1									Nut - Steering Wheel to column	
36H6009	36H6009	1	1									Contact Plate - Horn	
36H6034	36H6034	1	1									Slip Ring - Steering Wheel	
36H6031	36H6031	2	2									Spacer	
36H6033	36H6033	2	2									Escutcheon	
36M6000	36M6000	1	1									Switch - Indicators	
36H6038	36H6038	1	1									Impact Clamp	

Lotus Europa S1 Parts Manual - Section H1 - Steering - Column and Steering Unit - Page 4

Item	Lotus #	S1	S1A/B	S2	S2 Fed	TC	TC Fed	TCS	TCS F	LHD	RHD	Description	Change Point Notes Bulletin Reference
36H6032	36H6032	1	1									Washer	
36H6030	36H6030	2	2									Clip - Bellows - Steering Rack	
36H6027	36H6027	2	2									Bellows - Steering Rack	
36H6028	36H6028	2	2									Clip - Bellows - Steering Rack	
36H6012	36H6012	2	2									Locking Washer - Tie-Rod	
36H6011	36H6011	2	2									Spring - Tie-Rod Socket	
36H6010	36H6010	2	2									Socket - Tie-Rod Assembly	
36H6006	36H6006	2	2									Track Rod Assembly	
36H6007	36H6007	2	2									Ball joint - Track Rod (Tie Rod End)	
L08W0000	L08W0000	2	2									Washer	
36H6002	36H6002	2	2									Tie-Rod Adaptor	
36H6013	36H6013	2	2									Nut - Steering Rack	
36H6014	36H6014	2	2									Nut - Steering Rack	
36H6037	36H6037	1	1									Clamp - Steering Column to Facia	
XUFB0456	XUFB0456	4	4									Bolt - Mounting Bracket	3 1/2" long, 7/8" thread length, 1/4" x 28 TPI, 7/16" head